

STEPS TO DEPLOY A PRIVATE REEF

1. Locate acceptable materials.
2. Arrange for inspection of materials – Call 784-4025 and fill out application.
3. Inspection process: approval or modification suggestions; \$30.00 inspection fee to be paid upon completion of inspection.
4. 5-day waiting period for optional inspection by Coast Guard, Army Corp of Engineers, or Fish & Wildlife Enforcement.
5. Deploy reef in permitted site (currently 30 working days window) to deploy materials.
6. Return paperwork to Bay County Planning and Zoning Division via: Fax 850-914-6400; mail or in person: 707 Jenks Ave. Ste. B, Panama City, FL 32401